Silicone SR 30



Product Type	Condensation Cure Silicone		
Base	SR 30 Base		
Catalyst	SR 30 Standard		
Colour	White		

Applications

- Flexible Parts
- Casting Moulds for Polyester Resins Casting Moulds for Plastic
- Casting Moulds for Gypsum
- Casting Moulds for Wax
- Art Casting

Processing Data

Properties

- Excellent Flow Properties
- Replicates Fine Detail
- Flexible

Product		Silicone SR 30 Base	Silicone SR 30 Standard Catalyst
Colour		White	Clear
Mixing Ratio	P.B.W	100	5
Density at 25°C	g / cm ³	1.23	1.22
Pot Life 23 ^o C	Min.		60 - 90
Curing Time 23°C	Hrs.		8
Shrinkage	%		0.2 - 0.4

Physical Data

Properties	Test Method	Unit	Standard Catalyst
Elongation at Break	ISO 37	%	483
Tensile Strength	ISO 37	МРа	4.7
Tear Resistance		N/mm	23
Shore Hardness	DIN 53505	Shore A	27

After cure for 7 days at 23°C

All values are typical and not a specification

Sales Units (Packages)

Units

Base Catalyst

SR 30 Base Standard Catalyst 5.0 kg / 20.0 kg 0.25 kg / 1.0 kg

tooling resins

blocks

•

ancillaries

•

.

Silicone SR 30



Processing Instructions

Apply release agent to the master model once you have removed any loose paint or dirt. Use a single brush coat on the bare plaster - wet or dry. Allow the release agent to dry for about 20 minutes before pouring the Silicone SR 30. If the model is made of wood, clay or is painted, use a wax spray as a release agent.

Mixing Silicone SR 30 is easy. The mix ratio when using any of the catalysts is 100 parts of base to 5 parts catalyst, by weight. Simply pour the selected catalyst on top of the white base and start by folding the two components together gently; as they become inter-mixed you can mix with more vigour until a uniform colour is attained. Pay particular attention to the sides and base of the container. When you think it is mixed, pour the entire contents into another clean container and re - mix, this is the only way you can be sure the material is thoroughly mixed.

You can now pour the Silicone SR 30 over the model in a long steady stream, which helps burst any air bubbles introduced while mixing.

In General

Silicone SR 30 is a silicone moulding compound developed for plaster casting, resin casting and the model making industries. Moulds made from Silicone SR 2-1 will give a high quality reproduction with virtually no shrinkage and no risk of the plaster ever gripping to the mould surface.

It has been designed to be easy to mix by hand with colour-coded components to offer a visual aid to ensure mixing is complete. The two components mix easily and because of its low viscosity Silicone 30 can be used without the use of a vacuum chamber.

Storing

Storage at room temperature 18-40°C.

Opened containers should be closed immediately after use and should be used up as soon as possible.

Shelf life is indicated on the labels and is 12 months from date of manufacture.

Safety Measure

Please follow the precaution instructions of the Government Safety Organisation of the chemical industry when working with this material. Please follow safety advice.

Waste Disposal

According to arrangement with local authorities cured material can be disposed as domestic or commercial waste. Non-cured products are waste which is subject to

tooling resins	•	blocks	•	ancillaries	•	silicone	

Technical Datasheet

Silicone SR 30



inspection and has to be disposed accordingly. In case of further questions please do not hesitate to contact our Department for Product Safety.

The instructions and recommendations are given in good faith and are based on long experience and careful tests. Since the conditions of use are beyond our control, and due to versatility of applications and working methods, we can't give any guarantee. All information are non-binding and are no guarantee for special characteristics or properties of the product. Despite information given from **ebalta** the customer has to make his own tests regarding applications and processing. If any special warranty is requested, written agreement on this subject is essential.

tooling resins	•	blocks .	ancillaries	•	silicone
as of: Nov 2011		Revision: 1			Page: 3