

Processing instructions

The release wax is applied on the mould with a soft cloth or swam with circling movements by hand. After applying the wax can be polished with a soft cloth.

For of new moulds we recommend to apply 4 layers one after the other .

The release wax is suitable for epoxy resin, Polyurethane resin, Polydur and Polyester.

Working temperature range: suitable up to approx. 120°C

In General

ebalta T 7 is a pasty, polishable release wax, which can be applied and polished easily.

Density: 0,88 g/cm³

Flash point: >65 °C

Ignition temperature: > 210 °C

Sales units / packages: 0,425 kg tin

Storing

Keep away from ignition sources

Do not store outdoors.

Avoid storage temperature below 0° or higher than 30°C

In case of extreme cold do stabilize to 15 °C.

Storage at room temperature in closed containers 2 years.

Safety measure

Please follow the precaution instructions of the Government Safety Organisation of the chemical industry when working with this material. Please follow safety advices !

Waste Disposal

According to arrangement with local authorities cured material can be disposed as domestic or commercial waste.

Non-cured products are waste which is subject to inspection and has to be disposed accordingly.

In case of further questions please do not hesitate to contact our Department for Product Safety.

The instructions and recommendations are given in good faith and are based on long experience and careful tests. Since the conditions of use are beyond our control, and due to versatility of applications and working methods, we can't give any guarantee. All information are non-binding and are no guarantee for special characteristics or properties of the product. Despite information given from **ebalta** the customer has to make his own tests regarding applications and processing. If any special warranty is requested, written agreement on this subject is essential.

ebalta UK Limited . B2 Langham Park, Trent Lane . Castle Donington . Derbyshire DE74 2UT
t: +44 1332 814700 . f: +44 1332 814775 . e: info@**ebalta**.co.uk . w: www.**ebalta**.co.uk